
4.Enter to the advanced setting, then press the " $M/^{\odot}$ " for 9 times until appears the Heating Thermostat WIFI Debugging Diagram "FAC" 3 1. 1 ROOM TEMP SEN 0 0 3 A V 5.When appear the "FAC" button, then press the " button and up-regulation to "10" or "32" Iphone App (App store input "room heat") a. Android App 2.Fill in local WiFi name and WiFi password ●●●○○ 中国移动 令 16:46 @ 0 74% ●●●●○ 中国移动 令 16:30 ROOM TEM Equipment My Thermostat's Add a new device to the WIFI network: 0 A A 0 A A () 3 WIEI Name WIFI Password 6.Press (O) to turn off ROOM TEMP F 3 0 «Possible causes of wifi connection failure» Q 3 A A Configure Search 7.Press and hold on the " $^{\bigcirc}$ " button, then press the " $^{\bigcirc}$ ", the wifi icon begin to flashing Note:Wifi name can't include the sign "-" and "_" WiFi fast flashing 3.In power off state: Touch screen version: press and hold on the (\bigcirc) button, then press the (\bigcirc) together Button version: press and hold on the " \checkmark " button, then press the " \bigcirc " together. ROOM TEN Power-off Power-off O Μ 0 3 0 () A V



Press 🔒, lock or unlock thermostat	
Long press	Set Week loop: 12345,67
set weekly programmable.	Working day Program data set: Period 1: 6:00 20.0°C
	Period 2: 8:00 15.0°C
	Period 3: 11:30 15.0°C
	Period 4: 12:30 15.0°C
	Period 5: 17:00 22.0°C
	Period 6: 22:00 15.0°C Weekend Program data set:
	Period 1: 8:00 22.0°C
If want modify Period 1 temperature and	······· (#286a ♦ 54994 1785 €) < Set Week Program Data C
time please press 6:00 20.0°C As	Week loop: 12345,67 Working day Program data set:
time .please press 0.00 20.0 C .As	
right screenshot. It is same method to	Set Time 0°C
modify other period	4 58 .0°C 5 59
	6 00 AM Orc
	Brid 5: 17:00 22.0°C
	Period 6: 22:00 15.0°C Weekend Program data set:
	Period 1: 8:00 22.0°C
	G459M € 6459M € 600 C Advanced Data Setting
Press senior to set advanced option.As	Sensor mode setting(sen): In-s control Floor temp set(osv): 42°C
right screenshot	Floor temp ctri diff(dif): 2°C Room temp set max(svh): 35°C
	Room temp set min(svl): 5°C
	Room temp adjust(adj): 0.0°C Antifreeze set(fre): Close
	Power memory (PON): Off
Press to turn on or turn off	
Press Karual to switch auto or manual	
mode	